

Wall mount bracket for white analog PTZ cameras

DWC-P220WMW



WHAT'S IN THE BOX

4x plastic anchors (6pi)	4x machine screws, PH O-ring (M6x16)
4x tapping screws, PH (6x40)	4x machine screws, torque (M6x16)
4x machine screws, BH O-ring (M6x9)	1x quick setup guide
4x machine screws, PH O-ring (M4x16)	

NOTE: Download all your support materials and tools in one place.

1. Go to: <http://www.digital-watchdog.com/resources>
2. Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
3. Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.



Attention: This document is intended to serve as a quick reference for initial set-up. It is recommended that the user read the entire instruction manual for complete and proper installation and usage.

INSTALLING THE MOUNTING ACCESSORY

1. Using the mounting accessory, mark and drill the necessary holes in the mounting surface. The wall mount bracket must be attached to a structure such as hardwood, wall stud, concrete or a suitable material capable of supporting the final mount assembly.
2. Attach the wall mount bracket to the structure using the plastic anchors and tapping screws (PTS1 M6x40L) as illustrated in the figure.
3. Pass wires through the mounting accessory's access window, located on the bottom of the bracket.
4. Secure the camera to the wall mount using the safety wires and make the necessary connections to the camera. See the camera's manual for more information.
5. Use the machine screws included with the camera to attach the camera to the mounting bracket.
6. Once the camera is mounted securely to the mounting accessory, complete the installation by securing the camera's dome cover back on.

