1EGAPIX *PANO* Panoramic View IP cameras

DWC-PZ21M69TW DW

Default Login Information Username: admin

Password: admin WHAT'S IN THE BOX PoE Injector and Power 1 Cable

Waterproof Cap and Rubber Rings (Black: Ø0.15" (Ø4mm), White: Ø0.19" (Ø5mm)) 1 set Star Wrench (T-20) 1 Moisture Absorber and guide (recommended) ACCESSORIES REQUIRED TO INSTALL THE CAMERA (SOLD SEPARATELY) Parapet mount bracket: DWC-PZPARAMW (must be purchased with DWC-PZADPW) Ceiling mount bracket: DWC-PZCMW DWC-PZWMW

Go to: http://www.digital-watchdog.com/resources Search your product by entering the part number in the **'Search by Product'** search bar. Results for applicable part numbers will populate automatically based on the part number you enter.
3. Click **'Search'**. All supported materials, including manuals and quick start guide (QSGs) will appear in the results.

NOTE: Download all your support materials and tools in one place **Attention:** This document is intended to serve as a quick reference for the initial set-up. It is recommended that the user read the entire instruction manual for complete and proper installation and usage.

Read through this Installation Guide carefully before installing the product. Keep the Installation Guide for future reference. See the user manual for more information on the product correctly to avoid danger or property loss. Warnings: Serious injury or death may occur if any of the warnings are neglected.

Cautions: Injury or equipment damage may occur if any of the cautions are neglected.

IRNING

In the use of the product, you must be strict compliance with the electrical safety regulations of the nation and region. When the product is mounted on a wall or ceiling, the device shall be firmly fixed.

Be sure to use only the standard adapter specified in the specification sheet. Using any other adapter could cause fire, electrical shock, or damage to the product.

Make sure the power supply voltage is correct before using the camera. Incorrectly connecting the power supply or replacing the battery may cause an explosion, fire, electric shock, or damage to the product.

Do not connect multiple cameras to a single adapter. Exceeding the capacity may cause excessive heat generation or fire.

Securely plug the power cord into the power source. An insecure connection may cause a fire.

When installing the camera, fasten it securely and firmly. A falling camera may cause personal injury.

Do not install in a location subject to elevated temperature, low temperature, or high humidity. Doing so may cause fire or electric shock.

Do not place conductive objects (e.g. screwdrivers, coins, metal items, etc.) or containers filled with water on top of the camera. Doing so may cause personal injury due to fire, electric shock, or falling objects.

Do not install in humid, dusty, or sooty locations. Doing so may cause fire or electric shock.

Do not install near any heat sources such as radiators, heat registers, or other products (including amplifiers) that produce heat.

Keep out of direct sunlight and heat radiation sources. It may cause a fire. 3. 4. 5. 6. 8.

Keep out of direct sunlight and heat radiation sources. It may cause a fire.

If any unusual smells or smoke come from the unit, stop using the product at once. Immediately disconnect the power source and contact the service center. Continued use in such a condition may cause fire or electric shock. If this product does not operate normally, contact the nearest service center. Never disassemble or change this product in any way.

When cleaning the product, do not spray water directly onto parts of the product. Doing so may cause fire or electric shock. 13. 14. 15. electric shock CAUTION

- Use proper safety gear when installing and wiring the product.

 Do not drop objects on the product or apply strong shock to it. Keep away from a location subject to excessive vibration or magnetic interference. Do not use this product near water.
 The product shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the product. 5. Avoid aiming the camera directly towards extremely bright objects such as the sun, as this may damage the
- image sensor. The Main plug is used as a disconnect device and shall stay readily operable at any time. 6. damage to the product.

 Do not block any ventilation openings. Install following the manufacturer's instructions.

 A polarized or grounding-type plug is recommended for this product. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. If the provided plug does not fit into your outlet, consult an electrician for replacement.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.

 If any laser equipment is used near the product, make sure the surface of the sensor is not exposed to the laser 10. 11. beam as that may damage the sensor module.

 If you want to move the already installed product, be sure to turn off the power and then move or reinstall it.

 Proper configuration of all passwords and other security settings is the responsibility of the installer and/or 13. end-user.
- fi cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt.

 Do not touch the camera's lens or sensor module with fingers. If cleaning is necessary, please use a clean cloth to wipe it gently. If the device will not be used for a long time, please cover the lens cap to protect the device from dirt. Use only attachments/accessories specified by the manufacturer.

 Always use hardware (e.g. screws, anchors, bolts, locking nuts, etc.) compatible with the mounting surface and of sufficient length and construction to ensure a secure mount. Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the product. Unplug this product when a cart is used. Use caution when moving the cart/product combination to avoid injury
- 20. Refer all servicing to qualified service personnel. Servicing is needed when the product has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped. STEP 1 - PREPARING TO MOUNT THE CAMERA
- CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.
- This product is intended to be supplied by a UL Listed Power Supply Unit marked "Class 4" or "LPS" or "PS2" and rated 12 Vdc, 1800 mA min. 2. The wired LAN hub providing power over the Ethernet (PoE) in accordance with IEEE 802-3at shall be a UL Listed device with the output evaluated as a Limited Power Source as defined in UL60950-1 or PS2 as defined in
- UL62368-1. 4. Unit is intended for installation in a Network Environment 0 as defined in IEC TR 62102. As such, associated Ethernet wiring shall be limited to inside the building.
- b. Cut the card and folder along the dotted line. c. Place the moisture absorber at the top of the camera's cover, according to the diagram below.

Absorbers attachment point

Reset Button

Recorder

Recorder

NOTE: The camera will generate enough heat to dry moisture during operation. In cases where the camera can experience a moisture issue, keep the moisture absorber in the camera. The

6. Using the mounting template sheet or the camera itself, mark and

issues and damage the camera.

drill the necessary holes in the wall or ceiling.

Resetting the camera: Press the reset button for five (5) seconds to initiate a camera-wide

STEP 2 - POWERING THE CAMERA

DC12V, PoE IEEE 802.3at PoE+ class 4

waterproof cap, gasket and the 10

Connect the LAN cable to the camera's network port 0. 😉 will affix to 毡 with a ¼ turn

Thread and twist @ tightly to @.

white rubber ring.

When using the PoE+ injector, do not connect the PoE injector to a PoE/PoE+ switch

(High power PoE injector included)

reset of all the settings, including

network settings.

camera.

NOTE:

Power requirements

rubber ring.

Camera

Camera

counter-clockwise.

WARNING: Install the moisture absorber when mounting the camera.

moisture absorber has an approximately 6-month life cycle.

The moisture absorber prevents moisture buildup inside the camera's housing, which may cause image performance

5. Install the moisture packet at the top of the camera's cover. a. Remove the moisture absorber from the packaging.

Pass the wires through and make all necessary connections. When using a PoE Switch or PoE Injector, connect the camera using an Ethernet cable for both data and power.

2. When using a non-PoE Switch, connect the camera to the switch using an Ethernet cable for data transmission and use a power adapter to power the

Power consumption

PoE IEEE802.3at Class4: 23.2W


DC12V: 21.5W

or PoE/PoE+ enabled port of PoE/PoE+ switch. PoE Injector The waterproof cap set comes with two Ethernet Switch rubber rings. Use the rubber ring best suited for your network cable's diameter. Pass the LAN cable through the

> To ensure moisture seal, make sure the o-ring is in place between 📵 and 📵. In extreme environments use of an

Cables with ø4.5mm to ø5.5mm thickness should use the black rubber ring. Cables over ø5.5mm in thickness should use the

outdoor rated sealer is recommended.



UNLOCK

LOC

6 Alarm In/Out

Audio Input

WHITE

YELLOW SKY BLUE

GRAY + DOT

6 Alarm Output

Alarm Input

MAC Address

DWC-MF2Wi4T 00:0D:F1:21:66:92 192:168:10:159

Audio Output

DI (+)

DI (-)

DO(-) DO (+)

Network

STEP 5 - MANAGING SD CARDS

The card will pop out automatically.

STEP 6 - DW® IP FINDER™

Scan network

Bulk IP assignment

Network Setup

the right.

8.

contain the user ID.

information.

more information.

STEP 7 - WEB VIEWER

Webigital Watchbog

Detach the camera's cover by unscrewing the cover dome screws. Insert a Micro SD/SDHC Class 10 card according to the diagram below. 3. To remove the SD card, press the card gently into the card slot to release it.

SD card

NOTE: The camera has four (4) SD card slots, each assigned to a different sensor.

the camera's network settings or access the camera's web client.

Use the DW IP Finder software to scan the network and detect all MEGApix® cameras, set

マラ

@ 5

Follow the diagram below to connect the camera to external devices.

STEP 4 - CABLING

the selected network for all supported devices. Results are in the table. During the scan, the DW® logo will turn gray. 5. When connecting to the camera for the first time, a password must be set. To set up a password for your camera:

installation file and follow the installation instructions. 4. Open the DW IP Finder and click 'Scan Devices' to scan

a. Check the box next to the camera in the IP Finder's

c. Enter admin/admin for the current username and password. Enter a new username and password to

Passwords must have a minimum of 8 characters with at least 4 combinations of uppercase letters.

lowercase letters, numbers and special characters. Passwords cannot

6. Select a camera from the list by double-clicking on the camera's image or clicking on the 'Click' button under the IP Conf. column. The pop-up window will show the camera's current network settings, allowing admin users to adjust the settings as needed. To access the camera's web page, click on the 'View Camera Website' from the IP Config

To save changes made to the camera's setting, enter the username and password of the

W Camera Settings

DNS

Ports

Web Port

Control Port

Video Port

Username

×

DWC-MD421TIF 00:0D:F1:20:A4:9E

192.168.40 .1

search results. You can select multiple cameras.

b. Click "Bulk Password Assign" on the left.

d. Click "change" to apply all changes.

camera's admin account and click 'Apply'.

Default TCP/IP information: DHCP.

Port forwarding must be set in your

f Select "Static" to manually enter the camera's IP address, (Sub)Netmask, Gateway and DNS

1 The camera's IP must be set to static if

Contact your network administrator for

connecting to Spectrum® IPVMS.

Find the camera using the DW® IP Finder™

Tel: +1 (866) 446-3595 / (813) 888-9555

Rev: 10/22

Double-click on the camera's view in the results table.

To install the DW IP Finder, go to: http://www.digital-watchdog.com Enter "DW IP Finder" on the search box at the top of the page.

Go to the "Software" tab on the DW IP Finder page to download the

- network's router to access the camera from an external network. O Static IP IP Address 192,168,1 ,101 1 Select DHCP to allow the camera to receive Netmask 255.255.255.0 its IP address automatically from the DHCP 192.168.1 .1 Gateway server.

0

The GUI display may differ by camera models.

MOTION 1 2 3 4

- 3. Press the 'View Camera Website'. The camera's web viewer will open up in vour default web browser. 4. Enter the camera's username and password (default is admin/admin). NOTE: It is highly recommended that you change the camera's default admin password.
- 5. If you are accessing the camera for the first time, install the VLC player for web files in order to view video from the camera.

6. To adjust the camera's sensors alignment, go to the camera's settings.

- under Alignment configuration. See the camera's user manual for all setup options and configurations.
- NOTE: Some menu options may not be available based on the camera model. See the full manual for more information.

digital-watchdog.com

NOTE: 32bit version of VLC player must be installed. If you are using 64bit system, uninstall the previous 64bit version and reinstall using the 32bit version.

Technical Support Hours: 9:00AM - 8:00PM EST, Monday through Friday

SAFETY AND WARNING INFORMATION

WARNING

2.

9. 10.

15.

from tip-over.

- 1 set

- Quick Setup and Download Guides